

Installation instruction

WHIS[®]stone




reducing
traffic
noise

4SILENCE

Content


1. Preparatory work	2
2. Apply foundation	4
3. WHIS [®] stone	6



1. Preparatory work


STEP 1

Saw asphalt to create a straight connection




STEP 2

Remove the topsoil over a width of approx. 1.50 meters.




STEP 3

Remove the asphalt.



STEP 4

Excavate the cunet. (approx. 1.20 m wide x 0.49 m deep)




2. Apply foundation



The foundation must have sufficient load-bearing capacity and high drainage capacity.


STEP 5

Apply a layer of geotextile




STEP 6

Apply 0.20 m of granulate [8-16] and compact it with a vibratory plate.



STEP 7


Apply a thin layer of approx. 5 cm fine granulate [0-8] and level the layer at the correct height.
(Road surface minus 20 cm)




3. WHIS[®]stone



Always install the WHIS[®]stone with the deepest pockets and drainage slots towards the road. This side can be recognized by the notches on the side of the element.




STEP 8 WHIS[®]stone.




STEP 9


Add soil to the back of the WHIS® stone




STEP 10

Clean the roadway (and the if necessary) with a road cleaner.





This installation manual has been drawn up by 4Silence B.V. No rights can be derived from this manual. 4Silence B.V. is not liable for any damage caused by negligent handling during assembly.



Contact

Vliegveldstraat 100- C38
75224 PK Enschede

Bert Jan Danker (NL & DE):
+31 (0)6 53 86 11 21
Bart Willems (Int.):
+31 (0)6 15 02 59 28

www.4silence.com



reducing
traffic
noise